

Air Cooler Maintenance

Date	Check off type of maintenance:			Initial each when maintenance completed:			
	Weekly	Monthly	End of Season	Lab	Clinic 1	Clinic 2	Clinic 3

Per manufacturer, maintenance recommendations are:

- **Weekly:** drain tank and refill with cold tap water
- **Monthly:** drain tank, remove cooling media and carbon dust filter and water wash both, refill with cold tap water
- **End of season:** drain tank and wipe with damp cloth to remove mineral deposits, remove cooling media and carbon dust filter and water wash both, allow both to dry before re-assembling, run in “Fan” mode for minimum of 1 hour to dry internal parts before storage